



Dany Robberecht





Agenda

- Introduction Verhaert
- iTRACK technology
- INmotion system
- Collaboration





Leading Belgian new products & business development company









- Diversified system business
- System approach towards product development
- Strategic combination of product development and manufacturing services, resulting in complete solutions.
- Adaptable project driven organisation
- Long term strategic partnerships up-and down stream






Multi disciplinary resources

- Human Engineering
- Electronic Engineering
- Mechanical Engineering
- Industrial Design
- Software Engineering
- Applied Physics

All in-house disciplines to define, manage and develop complete systems







Areas of expertise









Integrated sensors

- selection and fusion of sensor principles; acoustic, optics electrical, chemical, bio sensors, inertial sensors, etc..
- development of algorithmes and processing software

Control Systems

- thermal, motion, environmental, fluid loops, etc.

Mechanisms & Robotics


- advanced mechanisms design
- innovative low cost mechanisms

Cabinets & Housings

- Human interfaces
- Harsh environments
- EMC shielding




Field of activities





History and background of inertial technology





Human motion capture powered by iTRACK





iTRACK Technology

ITRACK

Human Motion Systems

PNM

Navigatior

ALERT

INmotion

Virtual Reality

WTSS

Wearable
Training & &
Security
Systems

ITRACK SENSORS

ITRACK S50



TRACK S100



ITRACK M900



ITRACK PHERIPHERALS

Wave Mapper

Temperature compensation system

Datalogger

CPU Multi sensor data processing unit (PC104)


Bluetooth communication module





A broad range of applictions

Multi market solutions



Years innovation

Key applications

- Navigation
- Control & stabilisation
- Incident recording
- Simulation
























What is **IN**motion?

Advanced R&D program targetting to develop a new human mocap system based on proven technology







Program specifications


- No line-of-sight
- Full 3D
- Indoor / outdoor use (outdoor semi conditioned)
- Number of segments :
 - standard 5 (flexible set-up)
 - Goal 9-12 sensor positions
 - Segments can be changed in the field
- Accuracy target: 1° per segment
- Data-output: real time
 - = 4 quaternions per sensor @ 50 Hz
- Autonomy: 2h
- Near RT interface with Kaydara or another animation software package







Interface with animation software







iTRACK powering the ALERT system

Case Study ALERT

- Program objective
 Development of a motion capture system to support the virtual engineering programs of Renault and Peugeot
 - Improvement of cockpit ergonomics
 - Improvement of the assembly process (ergonomics)

Key features


- No 'line of sight' (in-car measurement)
- Good dynamic response (human motion)
- User friendly (set-up, during measurement sessions)
- Multiple actor motion capture





Slide 15

Case study 'ALERT': demonstrator set-up








Case studie 'ALERT': proof-of-technology

Proof-of-technology for movement of arms
















Pedestrian Navigation - PNM

- Functions:
 - distance
 - pattern
- Patented principle
 - orientation of upper and lower legs
 - back sensor for step direction
 - bio mechanical model
- Dead Reckoning

Applications

- Disabled persons
- Rescue & security

_








Pedestrian Navigation


Demonstrating the potential







Promising results



First tests indicate a good accuracy:

- Actual rravelled distance: 53 steps or 24m
- Accuracy: 30 cm of 0,5cm per step



Intelligent human mocap



Contact

Ann Van Mele Dany Robberecht

Verhaert New Products & Services nv Hogenakkerhoekstraat 21 9150 Kruibeke Belgium Tel +32 (0)3 250 14 14 Fax +32 (0)3 254 10 08 www.verhaert.com info@verhaert.com



